





How 3T specifies road bar size:

GETTING THE MEASURE

REACH



WIDTH



ERGOSUM